传导抗扰度试验

传导抗扰度测试 主要标准

- IEC/EN 61000-4-6 基本，工业和家用产品
 - ISO 11452-4 汽车
 - MIL-STD-461G 防御
 - RTCA DO-160C 航空电子设备

频率范围：

- IEC / EN 61000-4-6 150 kHz - 80 MHz (230 MHz)
- ISO11452-4 汽车电子 1 MHz - 400 MHz
- MIL-STD-461G 美军标 10 kHz - 400 MHz
- RTCA DO-160C 航空电子 10 kHz - 400 MHz

IEC/EN 61000-4-6 规定了150欧姆系统中开路电压的应力水平。所有其他标准都规定了注入电流的应力水平。

- IEC / EN 61000-4-6 CDN, BCI夹具、EM夹具
- ISO11452-4 BCI-夹具
- MIL-STD-461G BCI-夹具
- RTCA DO-160C BCI-夹具

IEC/EN 61000-4-6规定了上述任何换能器的抗扰度测试。然而，它明确优先考虑CDN，并规定了选择换能器的标准。CDN在从150千赫到80兆赫或从150千赫兹到230兆赫的频率范围内使用。对CDN的偏好来自于它们建立150欧姆的明确定义的RF阻抗的特性。

BCI夹具可用于将射频注入任何类型的电缆、电源线、数据线等。由于其非侵入性设计，它们非常容易应用。主要缺点是EUT和电源/AE之间缺乏去耦。BCI探头的带宽通常为150 kHz至100 MHz或250 MHz，用于EN 61000-4-6的抗扰度测试，或1 MHz至400 MHz，用于汽车抗扰度试验。

EM夹具用于无法使用CDN的地方。它们提供耦合和解耦。它们具有相对较低的插入损耗，因此只需要中等功率的RF放大器。它们可以在高达1GHz的频率范围内使用。

Line type	Examples	CDN - type
Power supply (AC and DC) and earth connection	AC mains DC in industrial installations Earth connection	CDN - Mx
Screened cables	Coaxial cables cables used for LAN and USB connections cables for audio systems	CDN - Sx
Unscreened balanced lines	ISDN lines telephone lines	CDN - Tx
Unscreened unbalanced lines	Any line not belonging to other groups	CDN - Afx or CDN - Mx

CDN的缺点：
它需要许多不同的型号

IEC 2627/13

CDN-M3, C_1 (typical) = 10 nF, C_2 (typical) = 47 nF, $R = 300 \Omega$, $L \geq 280 \mu\text{H}$ at 150 kHz

CDN-M2, C_1 (typical) = 10 nF, C_2 (typical) = 47 nF, $R = 200 \Omega$, $L \geq 280 \mu\text{H}$ at 150 kHz

CDN-M1, C_1 (typical) = 22 nF, C_2 (typical) = 47 nF, $R = 100 \Omega$, $L \geq 280 \mu\text{H}$ at 150 kHz

Figure D.2 – Example of simplified diagram for the circuit of CDN-M1/-M2/-M3 used with unscreened supply (mains) lines (see 6.2.2.2)

传导抗扰度测试

IEC 61000-4-6阻抗

- IEC/EN 61000-4-6测试模拟由射频发射器产生的电磁场引起的电磁干扰。
 - 测试设备对辐射干扰的敏感性。
 - 连接到设备的电缆表现为无源接收天线。关于电磁敏感性，假设连接的电缆处于谐振模式（ $\lambda/4$ 、 $\lambda/2$ 开放或折叠偶极子等），共模阻抗为 150Ω 。
 - 因此，测试装置通过耦合/去耦 150Ω 的设备来替代谐振电缆（=具有 150Ω 共模阻抗的天线） Ω 共模阻抗。
- CDN内部电阻器： 100Ω
- 与 50Ω 信号源阻抗： 150Ω
 - 众所周知，宽带射频功率放大器匹配不佳
 - 增加了一个 6 dB 衰减器，以改善CDN射频端口的匹配

	Frequency band		
Parameter	150 kHz – 24 MHz	24 MHz – 80 MHz	80 MHz – 230 MHz
I Common mode impedance I	$150\Omega \pm 20\Omega$	$150\Omega + 60\Omega / - 45\Omega$	$150\Omega \pm 60\Omega$

	Frequency band		
Parameter	150 kHz – 24 MHz	24 MHz – 80 MHz	80 MHz – 230 MHz
Voltage division ratio	$9.5\text{ dB} \pm 1\text{ dB}$	$9.5\text{ dB} \pm 1\text{ dB}$	$9.5\text{ dB} +3\text{ dB} / - 2\text{ dB}$

测试电平是在耦合设备的EUT端口设置的开路电压

Level	Voltage level (e.m.f.)	
	U_0 [V]	U_0 [dB μ V]
1	1	120
2	3	129.5
3	10	140
X*	Special	

* "X" can be any level, above, below or in between the others. The level has to be specified in the dedicated equipment specification

传导抗扰度试验

IEC 61000-4-6试验等级

为了测试设备，该信号用1 kHz正弦波进行80%幅度调制，以模拟实际威胁。有效调幅如下所示：

Consequently, the level of the modulated signal must be 5.1 dB higher than the test levels specified by the standard. The insertion loss of a typical CDN is approximately 10 dB from RF input to the output of a 150 Ohm to 50 Ohm adapter at the EUT port. Adding a 6dB attenuator to improve matching of the RF power amplifiers would require following amplifier output power:

Level	unmodulated rms voltage	modulated rms voltage	unmodulated RF power	modulated RF power	Including 6 dB attenuator
1	1 V	1.8 V	6 mW / 7.6 dBm	19 mW / 12.7 dBm	74 mW / 18.7 dBm
2	3 V	5.4 V	50 mW / 17 dBm	204 mW / 23.1 dBm	0.8 W / 29.1 dBm
3	10 V	18 V	0.55 W / 27.4 dBm	1.8 W / 32.5 dBm	7.1 W / 38.5 dBm

传导抗扰度测试 IEC 61000-4-6校准

请注意，指定的应力水平电压是EUT端口的开路电压。校准期间测量的电压必须乘以3才能进行50欧姆到150欧姆的转换，再乘以2才能达到开路电压。因此，在校准期间测得的电压是所需应力水平的电压的1/6。在对数图中，测得的电压比开路电压低15.5 dB。

EN 61000-4-6 calibration set up using EMCview PRO

示例电平3：10V；150的输出电平 Ω 至50 Ω -> $10/6=1.66V=17.4$ dBm分析仪输入处的相应电平：17.4 dBm-30 dB=-12.6 dBm

所需射频功率：

CDN插入损耗是在150欧姆适配器的输出端测量的，因此：

$$P=U0/6[\text{dBm}]+CDN\text{插入损耗}+6\text{ dB (衰减器)} +5.1\text{ dB (80\%AM RMS)} = \\ =17.4\text{ dBm}+10\text{ dB}+6\text{ dB}+5.1\text{ dB}=38.5\text{ dBm}$$

使用EMCview校准CDN设置:

The screenshot shows the EMCview Immunity software interface. The 'Immunity Test Setup Calibration' section contains a table with the following data:

Parameter	Value
Freq Start[Hz]	150000
Freq Stop[Hz]	80000000
Freq Step[%]	50
Calibration Level [dBm]	-7.45

Buttons for 'Calibrate', 'Abort Calibration', and 'Save Calibration File' are visible, with red numbers 4, 3, and 5 respectively. The 'Immunity Measurement' section shows a table with parameters like 'Calibration: none', 'Freq Start Sweep: 150000', etc. The 'Calibration Setup Calculator' section shows a block diagram with a 'Level 3' dropdown, 'Required RF power: 38.55 dBm = 7.16 W', and a 'Tekbox Modulated Amplifier' connected to a 'Spectrum Analyzer'. A 'Tekbox CDN' is also shown in the diagram. The 'Messages' section is empty.

步骤:

1. 根据图纸设置
2. 选择测试级别
3. 设置频率扫描
4. 开始校准
5. 保存校准文件

输出:

控制TG电平以在整个扫描过程中保持恒定干扰电压的校准文件

使用EMCview进行CDN免疫测试：

The screenshot shows the EMCview Immunity software interface. The 'Immunity Test Setup Calibration' section includes a table with the following parameters:

Parameter	Value
Freq Start[Hz]	150000
Freq Stop[Hz]	80000000
Freq Step[%]	50
Calibration Level [dBm]	-7.45

The 'Immunity Measurement' section includes a table with the following parameters:

Parameter	Value
Calibration	test1.icl
Freq Start Sweep[Hz]	none
Freq Stop Sweep[Hz]	test1.icl...
Freq Step Sweep[%]	1
Dwell Time Sweep[s]	1
Freq Single[Hz]	150000
Mode	sweep
Current Probe	none

The 'Test setup' diagram shows the following components and connections:

- AE or POWER SUPPLY** connected to the **AE-side** of the **Tekbox CDN**.
- The **EUT-side** of the **Tekbox CDN** is connected to the **EUT**.
- The **EUT** is connected to the **Tekbox Modulated Amplifier**.
- The **Tekbox Modulated Amplifier** is connected to the **Spectrum Analyzer**.
- The **Spectrum Analyzer** is connected to the **EMCview PRO** laptop.

步骤：

- 1.选择校准文件
- 2.选择扫描参数
- 3.启动抗扰度测试
- 4.监控EUT行为

使用EMCview校准脑机接口探头（EM夹具）设置：

The screenshot displays the EMCview Immunity software interface, which is used for setting up and performing immunity tests. The interface is divided into several sections:

- Immunity Test Setup Calibration:** This section contains a table of parameters for calibration, with buttons for 'Calibrate', 'Abort Calibration', and 'Save Calibration File'.

Parameter	Value
Freq Start[Hz]	150000
Freq Stop[Hz]	80000000
Freq Step[%]	50
Calibration Level [dBm]	-27.45
- Immunity Measurement:** This section contains a table of parameters for the measurement, with buttons for 'Play', 'Pause', 'Stop', and 'Refresh'.

Parameter	Value
Calibration	test1.icl
Freq Start Sweep[Hz]	150000
Freq Stop Sweep[Hz]	80000000
Freq Step Sweep[%]	1
Dwell Time Sweep[s]	1
Freq Single[Hz]	150000
Mode	sweep
Current Probe	none
- Calibration Setup Calculator:** This section shows the calculation of required RF power based on the selected standard and level.

Selected Standard: EN 61000-4-6 BCI

Level: Level 2

Required RF power[dBm][W]: 24.55 dBm = 0.28 W

The diagram below illustrates the calibration setup:

```

      graph LR
        Input[50 Ω] -- 100 Ω --> Att1[16 dB]
        Att1 --> Amp[Tekbox Modulated Amplifier]
        Amp --> Att2[30 dB]
        Att2 --> SA[Spectrum Analyzer]
        SA -- TG RF IN --> SA
        SA --> CalLevel[Calibration Level[dBm]: -27.45]
      
```
- Messages:** A text area for displaying messages, with 'clear' and 'Save' buttons.

以与CDN设置相同的方式进行BCI设置校准

使用EMCview进行BCI探头（EM夹具）设置的免疫测试：

The screenshot displays the EMCview Immunity software interface. The top menu includes File, Device, Setup, Mode, and About. The main window is divided into several sections:

- Immunity Test Setup Calibration:** A table with parameters and values, and buttons for Calibrate, Abort Calibration, and Save Calibration File.
- Immunity Measurement:** A table with parameters and values, and buttons for play, pause, stop, and refresh, along with checkboxes for TG ON Pause, Enable monitoring clamp, and Modulation=AM.
- Calibration Setup Calculator:** A section with tabs for EN 61000-4-6 CDN, EN 61000-4-6 BCI, and ISO 11452-4.

Below the software interface is a block diagram of the test setup:

- AE or POWER SUPPLY:** Connected to the **BCI Probe**.
- BCI Probe:** Connected to the **EUT** (Equipment Under Test).
- EUT:** Connected to the **Tekbox Modulated Amplifier**.
- Tekbox Modulated Amplifier:** Connected to the **Spectrum Analyzer**.
- Spectrum Analyzer:** Connected to the **EMCview PRO** laptop.

按照CDN设置中描述的不同方式执行抗扰度测试

传导抗扰度测试

ISO 11452-4, MIL-STD-461G, RTCA-DO-160C

ISO 11452-4、MIL-STD-461G、RTCA-DO-160C规定了注入电流的应力水平。

示例ISO 11452-4

ISO 11452-4 specifies BCI severity test levels as displayed in Table 2 and Figure 2:

Frequency band [MHz]	Test level I [mA]	Test level II [mA]	Test level III [mA]	Test level IV [mA]	Test level V [mA]
1 - 3	$60 \times f \text{ [MHz]}/3$	$100 \times f \text{ [MHz]}/3$	$150 \times f \text{ [MHz]}/3$	$200 \times f \text{ [MHz]}/3$	Specific values agreed between the users of this part of ISO 11452
3 - 200	60	100	150	200	
200 - 400	$60 \times 200/F \text{ [MHz]}$	$100 \times 200/F \text{ [MHz]}$	$150 \times 200/F \text{ [MHz]}$	$200 \times 200/F \text{ [MHz]}$	

Table 2: BCI test severity levels

Figure 2: Current level test limits

ISO 11452-4, MIL-STD-461G, RTCA-DO-160C 校准/测试

校准方法

替代
闭环

替换、校准设置

替换、测试设置

传导抗扰度测试

ISO 11452-4, MIL-STD-461G, RTCA-DO-160C
校准/测试

闭环设置

电流探头正在监测注入的电流。EMCview控制TG电平以保持设定电流

TEKBOX
DIGITAL SOLUTIONS

进一步信息，请联系我们！ www.ocetest.com
深圳市国测电子有限公司 0755-85261178

深圳市国测电子有限公司